

FEATURE MODULE 2 UPDATE

THIS PAGE UPDATES THE FOLLOWING
MERLIN™ CS
CUSTOMER DOCUMENTS:

ADMINISTRATION MANUAL: MODELS 1030 AND 3070 WITH FEATURE
MODULE 2, ISSUE 1

USER'S GUIDE: MODELS 1030 AND 3070 WITH FEATURE
MODULE 2, ISSUE 1

ATTENDANT'S GUIDE: MODELS 1030 AND 3070 WITH FEATURE
MODULE 2, ISSUE 1

SYSTEM ADMINISTRATORS: PLEASE READ THIS INFORMATION AND KEEP
IT WITH YOUR ADMINISTRATION MANUAL FOR FUTURE REFERENCE

ASSIGNING DIAL ACCESS TO POOLS (Administration Manual page 28):

Some voice terminals in your system may be equipped with an Automatic Multipurpose Adapter, a Manual Multipurpose Adapter, or a General Purpose Adapter. These adapters allow you to connect to your **MERLIN** Communications System such external devices as computers, facsimile machines, and answering machines. If you wish to dial calls from these devices, and have Dial Access to Line Pools, you must first do one of two things. On the voice terminal with the adapter attached, you must assign either a personal line or one of your line pools to a particular button. This personal line or assigned pool should be the first entry in the Automatic Line Selection sequence.

SETTING UP ALLOWED LISTS (Administration Manual page 35):

Please disregard the shortcut described in the NOTE section. If you have a sequence of several new entries for the same list, it is necessary to dial #5 and the list number for each entry. If you have a printer connected to your system for SMDR, you can get a printout of each list. To do so:

- Touch Adm Misc
- Dial # 5
- Dial the list number
- Dial any number 0 through 9
- Dial # 900

PROGRAMMING SYSTEM SPEED DIAL CODES (Administration Manual page 39):

Step 6 (b): Should read - Touch Adm Misc.

Step 4: Note that you can also program Transfer (for touch-tone enable) and ## (for # to access PBX/Centrex features) into a System Speed Dial sequence.

You can program a new System Speed Dial code over an old code without removing the old code first. If you want to remove a code without programming a new code, you dial the code (#60 - #99) that you want to clear and touch Drop (Stop) twice.

USING A SYSTEM SPEED DIAL BUTTON (User's Guide page 21):

To Program:

- T/P to P
- Touch the button
- Dial *95 + a System Speed Dial Code (60 through 99 - do not dial the #)
- T/P to center

To Place a call using a System Speed Dial button:
Lift your handset
Touch the button for the System Speed Dial code you want to dial.

ASSIGNING COVER BUTTONS (Administration Manual page 46; User's Guide page 30; Attendant's Guide page 13):

If a covered voice terminal's line is set to No Ring, outside calls for that voice terminal cannot be covered at another voice terminal.

SAVED NUMBER REDIAL AND LAST NUMBER REDIAL (User's Guide pages 22-23; Attendant's Guide page 34):

Saved Number Redial and Last Number Redial do not save Hold (Pause), Drop (Stop), Transfer (Touch-Tone Enable), or Recall/Hold (Switchhook Flash) special characters.

MESSAGE STATUS (Attendant's Guide page 22):

If you have a large attendant console, the Message Status button activates a green light beside the button. There are no red lights associated with the Message Status button.